

KW902 BT/WIFI Quick Start

Dear friends when you got this exquisite device please do the operations as following.



First Steps:

Install related software to your mobile-phone, if you mobile-phone using android system then please download the TORQUE from Android Market, if you mobile-phone is Apple phone (Or iPad) then please download Dashcommand from APP Store. After install the related software to your mobile-phone then all is finished. Of course you also can use the TORQUE and Dashcommand software from the CD of the device which we supplied to you. Please Referencing the following pictures.



Android



IOS

Third Steps: connect with mobile-phone

KW902(wifi) don't need the password to make verification, open the 'Settings' of your mobile phone, select the WLAN, click the (KONNWEI OBDII) then finished operation.

KW902(Bluetooth) need the password to make the verification, open the 'Setting' of your mobile phone, unfold the Bluetooth, click the 'Bluetooth setting' and scan the Bluetooth, choose 'KONNWEI OBDII' and put the 1234 as password, then finished all operation.



Forth Steps:

After connection and setting, back out, and open the related software TORQUE or Dashcommand, then respectively doing several settings as following:

Second Steps:

Connect the bought KW902 to your Car OBD interface, you can find the light of the KW902 will flash (it shows the the connection is good), then it coming in standby and waiting for working. Usually the CAR OBD interface were under the steering wheel (above of the brake), some are hidden in the tool box of the hand brake, you can reference the following picture to find it.



NOTE!!!the switching function of KW902:

don't need to draw the KW902 after the car stall (but still have power supply), 30 minutes later it will automatically come to sleep mode and stay in power saving condition. Tomorrow morning or next time to start the vehicle you can use the KW902 directly only by press the switch not need do plug again, you don't needed to make mobile-phone connection again, it can connect to it automatically.

1. Open Dashcommand, select 'setting', click OBD II interface', choose ELM, do prepermission as instructions, then exit and back. Reopen the software, then can connect automatically and read data.

2. open TORQUEhou, select 'setting', click OBD adapter setting, choose the connection (Bluetooth) and select KONNWEI OBDII, then exit and back. Reopen the software, then can connect automatically and read data.

